



White fine wires (2) go to collector SAS-3 sensor

Orange fine wires (2) go to storage SAS-3 sensor

Grey fine wires (2) go to storage high limit SAS-3 sensor

When used for freeze recycle, the FS-4 sensor is wired in parallel with the collector SAS-3 sensor. (Mode 2)

When used to hold the pump off, the OPB-6-80 sensor is wired in series with the the collector SAS-3 sensor. (Mode 1)

Blk
120 volt output
to pump
White

DTT-80 wiring information